



The care of the screws:

Basically, we assume that you use a high-quality tool and the right tool size during cultivation and carefully deal with the naturally softer material stainless steel.

!! Important !!

When attaching any screws screwed into an aluminum component, care must be taken to apply copper spray, anti-seize mounting or screw paste to the thread.

This prevents the screw from being tightened.

In places where there is no seal and steel meets steel, the screw should be secured with a screw lock (medium strength).

You can find possible products in our shop at:
(<https://www.old-skull-brothers.com/en/motorcycle-parts/maintenance-safety/>)

Special feature of the color black:

Screws in the color black are coated by hand with a thin layer of universal oil shortly before shipping.

Over time, this layer of oil wears off, which happens, for example, when cleaning the motorcycle or due to weather conditions and is therefore unavoidable.

In order to restore the original shine, we recommend that you spray the screws with a universal oil. Then wipe the "wet" screw with a dry microfiber cloth and et voilà!